

# Luxury Backlit Metal Signs Wiring Diagram

**NOTE:** ONLY ELECTRICIAN CAN WIRE THIS PRODUCT, MUST CAREFULLY CHECK AND CONFIRM EACH TERMINAL; THIS DIAGRAM IS FOR ILLUSTRATION PURPOSES, ACTUAL WIRE LOCATION TO BE CONFIRMED TO THE REAL PRODUCT.



## READ BEFORE START:

- The LED neon flex signs would be fix on a laser cutting clear acrylic panel by default, and we will finish the signs cables parallel connecting job.
- The cables of the LED neon flex signs can not connect to the AC power supply directly.
- We suggest using the cable 2.5 SQ mm as the main connecting cable.
- The distance between the AC transformer and the LED neon flex signs part within 5 meters (too much exhaust of low voltage DC).
- AC transformer needs to be grounded during installation.
- Use the connecting cable to connect the Input of AC transformer to AC power supply.
- Please give the AC transformer enough space for radiating heat. If the space have the ventilation system would be better.

If there are any questions please contact us.

